



4/6"5CCT IN 1

GIMBAL LED RECESSED LIGHT

This instruction manual applies to the following products



4 inch



6 inch

Should you experience any issues while operating any of our products, you can directly reach out to our Customer Support via Amazon Orders. Or you can send your inquiry to our Official Customer Support at:

 support@amicolight.com

 +1(888) 676-1042 Monday - Friday from 9:00AM - 5:00PM (PT)



SAFETY INFORMATION

IMPORTANT

READ ALL INSTRUCTIONS BEFORE INSTALLING FIXTURES.
RETAIN FOR FUTURE REFERENCE.

SAFETY

For your safety, this fixture must be wired in accordance to local electrical codes and ordinances. All work should be done by a qualified electrician.

ASSEMBLY INSTRUCTIONS


1. Preparing for installation: disconnect electrical power before installing or servicing any part of this fixture.
2. Locate a suitable position to plate the fixture and open in accordance to the cut-hole dimensions (refer to hole cut table for appropriate size).
3. Run electrical wire from the switch (power supply) through the mounting hole—use nmd90 romex or bx cable.

WARNING

- Make certain power is off from the electrical panel before starting installation or attempting any maintenance. Indoor installation only.
- Risk of fire or electrical shock. Do not alter, relocate or remove wiring, junction box, power supply or any other electrical components.
- Suitable for Wet Locations.
- To prevent electrical shock, please wear rubber shoes and work gloves when installing the fixture.



INSTALLATION VIDEO



Need a Video Instruction Guide?
Please scan the QR code.

If the QR code is invalid, please contact us for the video.









4"5CCT IN 1 GIMBAL LED RECESSED LIGHT

1. Connect the wires on the lamp to the corresponding wires and install the wire caps. See Fig1.
2. Use your hands to pull the spring on the lamp down and then clip it onto the hook of the mounting tube. See Fig2.
3. Push the lamp upwards into the mounting tube with your hands, so that the outer edge of the lamp is level with the ceiling. See Fig3.

6"5CCT IN 1 GIMBAL LED RECESSED LIGHT

1. Connect the wires on the lamp to the corresponding wires and install the wire caps. See Fig3.
2. Use your hands to pull the spring on the lamp down and then clip it onto the hook of the mounting tube. See Fig4.
3. Push the lamp upwards into the mounting tube with your hands, so that the outer edge of the lamp is level with the ceiling. See Fig5.





PRODUCT FEATURES

4"5CCT IN 1 GIMBAL LED RECESSED LIGHT

Color Temperature	2700K/3000K/4000K/5000K/6000K
Watts	9W
Default Driver Input	120V, 60Hz
CRI	90
Beam Angle	100° (±5)
Intelligent Dimmer	10% - 100%
Material	Aluminum+PC

6"5CCT IN 1 GIMBAL LED RECESSED LIGHT

Color Temperature	2700K/3000K/4000K/5000K/6000K
Watts	12W
Default Driver Input	120V, 60Hz
CRI	90
Beam Angle	100° (±5)
Intelligent Dimmer	10% - 100%
Material	Aluminum+PC



DIMMER COMPATIBILITY GUIDE

BRAND	MODEL	STAR RATING
LEVITON	6672	★ ★ ★ ★ ↘
	RNL06	★ ★ ★ ★ ↘
	DSL06	★ ★ ★ ★ ↘
	6674	★ ★ ★ ★ ↘
LUTRON	CTCL-153P	★ ★ ★ ★ ↘
	TGCL-153PH-LA	★ ★ ★ ★ ↘
	DVCL-153P	★ ★ ★ ★ ↘
	MSCL-OP153M	★ ★ ★ ★ ↘
	CT-103PR-WH	★ ★ ★ ★ ↘
	DVWCL-153PH	★ ★ ★ ★ ↘
	RCL-153RNL	★ ★ ★ ★ ↘
	DVRF-6L	★ ★ ★ ★ ↘
	CTCL-150H	★ ★ ★ ★ ↘




COMMON TROUBLESHOOTING

PROBLEMS AND COUNTERMEASURES


PROBLEM	PROBABLE CAUSE	SOLUTION
Unlit	The wire falls off/loosens/breaks	Check that the wires are well connected
	The power switch is not turned on	Ensure that the power switch is on
	Voltage is too high, product is damaged	Ensure that the voltage is 120V
	None of the above	Reach out to our Customer Support
Dim	Incompatible dimmer	Check and choose a dimmer from the recommended dimmer list
	Not setting the dimmer right	Check dimmer Settings
	Too many lights are connected to one dimmer	Total Power Of the Lights \leq 75% of the Rated Power of the Dimmer
	The brightness of lighting is too low	Install more lights and recommended spacing for installation of 4" lights: 2-4ft, & 6" lights: 5-7ft
	The brightness of lighting is too high	Lower the dimmer or reduce the number of lights at the same time
	Mix the junction boxes (4" and 6")	Check if the junction box matches
	The product is not installed in place	Check the product installation steps to ensure that the springs and other parts are normal
None of the above	Reach out to our Customer Support	
Flickering	The wire falls off/loosens/breaks	Check that the wires are well connected
	Incompatible dimmer	Check and choose a dimmer from the recommended dimmer list
	Too many lights are connected to one dimmer	Total Power Of the Lights \leq 75% of the Rated Power of the Dimmer
	High-power electrical appliances on the same circuit	Reduce the number of lights at the same time
	Voltage is too low	Check the circuit voltage to make sure the voltage is 120V
None of the above	Reach out to our Customer Support	
Over-heating	Too many lights are connected to one dimmer	Total Power Of the Lights \leq 75% of the Rated Power of the Dimmer
	None of the above	Reach out to our Customer Support



- ① Log into your Amazon.com account, click "Returns&Orders" on the top-right corner.




- ② Find your order in the list and click "View order details".



- ③ Click the "store name" following the Sold by, below the product title.

Delivered yesterday



Sold by: [store name]

Serial Numbers:


AZ: [serial numbers]

Return eligible through Sep 8, 2021

\$49.99



④ Click the yellow button "Ask a question", on the top-right corner, to contact the seller.



Should you experience any issues while operating any of our products, you can directly reach out to our Customer Support via Amazon Orders. Or you can send your inquiry to our Official Customer Support at:

Call us:

+1(888) 676-1042

Monday - Friday from 9:00AM - 5:00PM (PT)

Contact via Email: support@amicolight.com



01 30-Day Return Policy

If you're not completely satisfied with your purchase, simply return the merchandise via Amazon Orders.

Unused merchandise can be refunded or exchanged within 30 days from the original purchase date.

02 2-Year Warranty

We guarantee your product is free from defects in product material and workmanship for two (2) years starting from the date of purchase during normal use of household conditions. If your appliance fails to operate properly within our warranty period, we will arrange a new replacement free of charge and cover all the shipping costs.

03 Quick Response within 12 Hours

If you are still unable to resolve the issue you are experiencing, please contact us immediately at our support email. It doesn't matter if the product has been installed, our customer support team will respond within 12 hours and assist you quickly and efficiently. The most efficient way to confirm your problem to us is to attach a video illustrating your product issue.

GET MORE SUPPORT

Should you experience any issues while operating any of our products, you can directly reach out to our Customer Support via Amazon Orders. Or you can send your inquiry to our Official Customer Support at:

✉ support@amicolight.com

☎ +1(888) 676-1042 Monday - Friday from 9:00AM - 5:00PM (PT)