

4" 5CCT IN 1 LED RECESSED LIGHT




Should you experience any issues while operating any of our products, you can directly reach out to our Customer Support via Amazon Orders. Or you can send your inquiry to our Official Customer Support at:

 support@amicolight.com

 +1(888)676-1042 Monday - Friday from 9:00AM - 5:00PM (PT)



INSTALLATION VIDEO



Need a Video Instruction Guide?
Please scan the QR code.

If the QR code is invalid, please contact us for the video.




SAFETY INFORMATION


1. DANGER - Risk of shock- Disconnect power before installation.
2. WARNING - Risk of fire or electric shock. Installation of this retrofit assembly requires a person familiar with the construction and operation of the luminaire's electrical system and the hazard involved. If not qualified, Do not attempt installation. Contact a qualified person.
3. Suitable for damp locations. For indoor use only.
4. Suitable for Type IC or NON-IC Luminaires.
5. WARNING - To prevent wiring damage or abrasion, Do not expose wiring to edges of sheef metal or other sharp objects.
6. This device is not intended for use with emergency exits.
7. WARNING - Risk of fire or electric shock. Install this kit only in the luminaires that has the construction features and dimensions shown in the photographs and /or drawings and where the input rating of the retrofit kit does not exceed the input rating of the luminaire.
8. Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation.
9. The retrofit kit is accepted as a component of a luminaire where the suitability of the combination shall be determined by authorities having jurisdiction. Product must be installed by a qualified electrician in accordance with the applicable and appropriate electrical codes. The installation guide dose not supersede local or national regulations for electrical installations.



HOW TO INSTALL



1. Turn off circuit breaker that provides power to the light switch for the recessed lights.
2. Thread the Socket Adapter into the socket.
3. The toggle switch to the specified color temperature.



4. Plug the female connector of the retrofit trim onto the male connector of the housing.
5. Push the connected downlight vertically upwards into the can.
Tuck all wires into the can and carefully push the retrofit trim into can
(Note: to provide enough room in shallow cans carefully position SOCKET ADAPTER and SOCKET adjacent to the side of the LED DRIVER prior to inserting the RETROFIT TRIM into the CAN).
6. Turn on circuit breaker and test light.



PRODUCT FEATURES

SPECIFICATIONS

Color Temperature	2700K/3000K/4000K/5000K/6000K
Watts	7W
Standard luminous flux	700LM
Colour	White
Default Driver Input	120V / 60Hz
CRI	80
Beam Angle	120°
Intelligent Dimmer	5%-100%
Operating Temp	-4°F-104°F



COMMON TROUBLESHOOTING

PROBLEMS AND COUNTERMEASURES

PROBLEM	PROBABLE CAUSE	SOLUTION
Unlit	The wire falls off/loosens/breaks	Check that the wires are well connected
	The power switch is not turned on	Make sure the power switch is on
	The light holder in the UL cans is damaged	Check and replace with a new light holder
	Loose connection between E26 adapter and light base	Check the E26 adapter and light holder are well installed
	Loose connection on TP24 connector	Change the TP24 connector
	The voltage is too high and the product is damaged None of the above	Make sure the voltage is 120V Reach out to our Customer Support
Dim	The wire falls off/loosens/breaks	Check the wires are well connected
	Incompatible dimmer	Check the dimmer model with the manual
	Not setting the dimmer right	Check dimmer settings
	Too many lights are connected to one dimmer	Reduce the number of lights connected to a dimmer (the total power of the lights should be less than 75% of the rated power of the dimmer)
	The brightness of lighting is too low	Install more lights 4inch: 2-4ft; 6inch: 5-7ft
	The brightness of lighting is too high	Turn down the dimmer or reduce the number of lights on at the same time
	Voltage is too low	Check the voltage to make sure it is 120V
	Loose connection between E26 adapter and light base The light is not installed correctly	Check the E26 adapter and light holder are well installed Check the installation of the light, to ensure that the springs and other parts are normal
Flickering	The wire falls off/loosens/breaks	Check the wires are well connected
	Incompatible dimmer	Check the dimmer model with the manual
	Not setting the dimmer right	Check dimmer settings
	Too many lights are connected to one dimmer	Reduce the number of lights connected to a dimmer (the total power of the lights should be less than 75% of the rated power of the dimmer)
	High-power electrical appliances on the same circuit	Reduce the number of lights light on the same time
	Voltage is too low Loose connection between E26 adapter and light base	Check the line voltage to make sure the voltage is 120V Check the E26 adapter and light holder are well installed
Falls	No C-clamp on the can	Replace the can, or install the C-clamp
	The can has C-clamp but the spring was not fixed in the clamp	Re-install
	The spring is loose	Reach out to our Customer Support




DIMMER COMPATIBILITY GUIDE


Brand	Model	Star Rating
LUTRON	PD6WCL	★ ★ ★ ★ ↘
	MSCL-OP153M	★ ★ ★ ★ ↘
	CN-600P	★ ★ ★ ★ ↘
	DVCL-153P2.1	★ ★ ★ ★ ↘
	SCL-600P	★ ★ ★ ★ ↘
	SLV-600P	★ ★ ★ ★ ↘
	MACL-153M	★ ★ ★ ★ ↘
	DV-600P	★ ★ ★ ★ ↘
LEVITON	IPL06	★ ★ ★ ★ ↘
	DSL06	★ ★ ★ ★ ↘
	IPI06	★ ★ ★ ★ ↘
	6674	★ ★ ★ ★ ↘
	6631	★ ★ ★ ★ ↘



- ① Log into your Amazon.com account, click "Returns&Orders" on the top-right corner.



- ② Find your order in the list and click "View order details".



- ③ Click the "store name" following the Sold by, below the product title.

Delivered yesterday





- ④ Click the yellow button "Ask a question", on the top-right corner, to contact the seller.

Livestreams

Outdoor Recreation

Save on school essentials

Have a question for 

Ask a question

Should you experience any issues while operating any of our products, you can directly reach out to our Customer Support via Amazon Orders. Or you can send your inquiry to our Official Customer Support at:

Call us:

+1(888)676-1042

Monday - Friday from 9:00AM - 5:00PM (PT)

Contact via Email: support@amicolight.com



01 30-Day Return Policy

If you're not completely satisfied with your purchase, simply return the merchandise via Amazon Orders.

Unused merchandise can be refunded or exchanged within 30 days from the original purchase date.

02 2-Year Warranty

We guarantee your product is free from defects in product material and workmanship for two (2) years starting from the date of purchase during normal use of household conditions. If your appliance fails to operate properly within our warranty period, we will arrange a new replacement free of charge and cover all the shipping costs.

03 Quick Response within 12 Hours

If you are still unable to resolve the issue you are experiencing, please contact us immediately at our support email. It doesn't matter if the product has been installed, our customer support team will respond within 12 hours and assist you quickly and efficiently. The most efficient way to confirm your problem to us is to attach a video illustrating your product issue.



GET MORE SUPPORT

Should you experience any issues while operating any of our products, you can directly reach out to our Customer Support via Amazon Orders. Or you can send your inquiry to our Official Customer Support at:

 support@amicolight.com

 +1(888)676-1042 Monday - Friday from 9:00AM - 5:00PM (PT)

MADE IN CHINA