


# 6" 50CT IN 1 LED DISK LIGHT

---



Should you experience any issues while operating any of our products, you can directly reach out to our Customer Support via Amazon Orders. Or you can send your inquiry to our Official Customer Support at:

✉ [support@amicolight.com](mailto:support@amicolight.com)

☎ +1(888) 676 -1042 Monday - Friday from 9:00AM - 5:00PM (PT)



# SAFETY INFORMATION

## IMPORTANT

Please read carefully and save these instructions, as you may need them at a later date. When using electrical equipment, basic safety precautions should always be followed as below:


### GENERAL:

All electrical connections must be in accordance with local and National Electrical Code (N.E.C) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

1. Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation.
2. To prevent wiring damage or abrasion do not expose wiring to edges of sheet metal or other sharp objects.
3. Suitable for damp locations.
4. Use only in open luminaires.
5. This device is not intended for use with emergency exit.
6. This fixture is dimmable. Dimming range is 5%-100%. Please refer to below compatible dimmer list.



# INSTALLATION VIDEO



Need a Video Instruction Guide?  
Please scan the QR code.

If the QR code is invalid, please contact us for the video.



# ACCESSORIES LIST

**A x1**



LED Disk Light

**B x2**



Spring

**C x1**



E26 BASE

**D x3**



Wire Nut

**E x2**



Longer Screws

**F x2**



Shorter Screws




# HOW TO INSTALL

**WARNING:** Risk of fire or electric shock disconnect main power at fuse or circuit breaker before installing or servicing the fixture.

## Surface mount


### Step 1



Junction Box

1. Make sure power is turned off at the source before installing the fixture and the J-box is securely mounted.  
( This fixture is compatible with 2.75" or 3.5" J-box.)

### Step 2




2. Screw out the module counterclockwise.




# HOW TO INSTALL

## Step 3



3. fixture with the holes in the J-box depending on the size of the box ( 2.75" or 3.5" ). Use the longer screws for a deep J-box or the shorter screws for a shallow J-Box to attach the mounting fixture, flush with the ceiling. Do not over tighten screws or fixture will not be tight to ceiling.

## Step 4




4. Connect the supply wires to the wires on the fixture using the three wire nuts included in the packaging. Attach white to white and black ( red ) to black by pushing the wires into the wire nuts. Also attach green wire to copper wire ( green ) as grounding connection using the wire nut.



# HOW TO INSTALL

## Step 5




5. Complete the installation by placing the module back into its original position by twisting it in clockwise direction.



# HOW TO INSTALL

## Retrofit


### Step 1.2



Compatible Housing Can

1. Make sure power is turned off at the source before installing the fixture.
2. Remove any existing trim prior to installation of this fixture.

### Step 3




3. Insert the spring down into the slot.




# HOW TO INSTALL

## Step 4



4. Connect the power wires from the E26 Adapter to the wires on the fixture using the two wire nuts included in the packaging. Attach white to white and black (red) to black by pushing the holds into the wire nuts.

## Step 5.6



5. Thread the E26 Adapter into the socket of the Recessed can.
6. Squeeze both the holders arms together and insert into the spring slots of the can.



## SELECTING DOWNLIGHT OR NIGHTLIGHT MODE

### 1. Turn on the main downlight: Turn on the light switch to activate the light fixture

The product can be used in one of two modes: downlight mode, which provides full brightness and allows selection from five color temperatures, or nightlight mode. Nightlight mode provides reduced light output at 2000K color temperature for very soft illumination at night.

### 2. Convenient control using light switch.

**NOTE:** The main downlight will not provide light output when the nightlight trim is illuminated.

After turning off the light for 8 seconds, the light will be reset to downlight mode when it is turned back on, the purpose is to ensure the consistency of the mode of all downlights.

No change No nightlight mode with reduced light output from the trim ring: Switch the downlight off and back on again within 3 seconds to activate nightlight mode.






# DIMMER COMPATIBILITY GUIDE


BRAND	MODEL	STAR RATING
LEVITON	IPI06	★ ★ ★ ★ ↘
	6674	★ ★ ★ ★ ↘
	6672	★ ★ ★ ★ ↘
	6613-P	★ ★ ★ ★ ↘
	IPE04	★ ★ ★ ★ ↘
	IPL06	★ ★ ★ ★ ↘
LUTRON	AY-600P	★ ★ ★ ★ ↘
	DV-600P	★ ★ ★ ★ ↘
	CL-600H	★ ★ ★ ★ ↘
	MACL-153M	★ ★ ★ ★ ↘
	AYCL-153P	★ ★ ★ ★ ↘
	TGCL-153P	★ ★ ★ ★ ↘
	DV603PG	★ ★ ★ ★ ↘
	DVCL-253P	★ ★ ★ ★ ↘
	LTCL-153P	★ ★ ★ ★ ↘
	DVCL-153P	★ ★ ★ ★ ↘
COOPER	DLC03P	★ ★ ★ ★ ↘



- ① Log into your Amazon.com account, click "[Returns&Orders](#)" on the top-right corner.



- ② Find your order in the list and click "[View order details](#)".



- ③ Click the "[store name](#)" following the Sold by, below the product title.

## Delivered yesterday





- ④ Click the yellow button "Ask a question", on the top-right corner, to contact the seller.

Livestreams Outdoor Recreation Save on school essentials

Have a question for **Member name**

Ask a question

Should you experience any issues while operating any of our products, you can directly reach out to our Customer Support via Amazon Orders. Or you can send your inquiry to our Official Customer Support at:

## Call us:

+1(888) 676-1042

Monday - Friday from 9:00AM - 5:00PM (PT)

**Contact via Email:** [support@amicolight.com](mailto:support@amicolight.com)



## 01 30-Day Return Policy

If you're not completely satisfied with your purchase, simply return the merchandise via Amazon Orders.

Unused merchandise can be refunded or exchanged within 30 days from the original purchase date.

## 02 5-Year Warranty

We guarantee your product is free from defects in product material and workmanship for five (5) years starting from the date of purchase during normal use of household conditions. If your appliance fails to operate properly within our warranty period, we will arrange a new replacement free of charge and cover all the shipping costs.

## 03 Quick Response within 12 Hours

If you are still unable to resolve the issue you are experiencing, please contact us immediately at our support email. It doesn't matter if the product has been installed, our customer support team will respond within 12 hours and assist you quickly and efficiently. The most efficient way to confirm your problem to us is to attach a video illustrating your product issue.



## GET MORE SUPPORT

Should you experience any issues while operating any of our products, you can directly reach out to our Customer Support via Amazon Orders. Or you can send your inquiry to our Official Customer Support at:

✉ [support@amicolight.com](mailto:support@amicolight.com)

☎ +1(888) 676-1042 Monday - Friday from 9:00AM - 5:00PM (PT)

**MADE IN CHINA**